ZURLINDEN
GRUPPE

INSTRUCTIONS DOCUMENT

PROCEDURE TO CLEAR COAT AUTOCLAVE CARBON FIBER PARTS

1. Wipe panel with Kantstick Mold Cleaner
2. Wipe panel with Acetone
3. Gently sand/scuff panel with Maroon (320-grit) 3M Scotch-Brite pad
4. Wipe panel with Acetone
5. Wipe panel with Polycracker Prep Wash
6. Wipe panel with DX 330
7. Wipe panel with BASF 900
8. Wipe panel with BASF 700-1
9. Wipe panel second time with BASF 700-1

IMPORTANT: Do not let products dry out on surfaces. WIPE DRY between steps.